

Pre-setting tools



- Pre-setting key included
- Pre-setting of Kv-value
- Different tools for different valves

Description *Pre-setting tools*

Area of use

By using a pre-setting tool, it's easy and simple to set the Kv value.

Description



The pre-setting tools are available in different variants, depending on the valve.

480 61 02 FV 4	Pre-setting tool for TP and MMA-manifold with banjo connection. (grey) FN2 incl..	
480 61 03 FV 5	Pre-setting tool for FV-series all dim. and MMA Flex-manifold. (black) FN2 incl.	
480 63 58 FV 8	Pre-setting tool for FVX-series. (red) FN2 incl.	
480 56 63 FV 9	Pre-setting tool FLK for Flexibel. (orange) FN2 incl.	
480 66 60 FV 18	Pre-setting tool for STVT15. (green) FN2 incl.	
480 66 61 FV 19	Pre-setting tool for STVT20. (green) FN2 incl	

Description *Pre-setting tools*

480 70 07 FV 21	Pre-setting tool for FVRe. (light green FN2 incl.	
481 20 83 FV 22	Pre-setting tool for Evoflow FN2 incl.	
480 68 21 FVI	Pre-setting tool FVI insert	
480 56 55 FV 1	Pre-setting tool for AN-series. (white) FN incl.	
480 56 56 FV 2	Pre-setting tool for RN15. (green) FN incl	
480 56 57 FV 3	Pre-setting for RNT-insert. (yellow) FN incl	
480 56 59 FL	Pre-setting tool box. Containing FV1, FV3, FV4, FV5, FV21, FV22, FN och FN2	

Product information *Pre-setting tools*

480 61 04 FN 2	Pre-setting key for FV4, FV5, FV8, FV9, FV18, FV19, FV21 och FV22. (grey wheel with splines)	
480 56 58 FN	Pre-setting key for FV1, FV2 and FV3. (blue wheel with pins)	

Ordering codes

RSK - number	Article number	Designation	Description
480 61 02	4873804	FV 4	Pre-setting tool. FN2 incl
480 61 03	4873805	FV 5	Pre-setting tool. FN2 incl
480 63 58	4873808	FV 8	Pre-setting tool. FN2 incl
480 66 60	4873818	FV 18	Pre-setting tool. FN2 incl
480 66 61	4873819	FV 19	Pre-setting tool. FN2 incl
480 70 07	4873821	FV 21	Pre-setting tool. FN2 incl
481 20 83	4873822	FV 22	Pre-setting tool. FN2 incl
480 68 21	48331014	FVI key	Pre-setting tool
480 56 55	4873801	FV 1	Pre-setting tool. FN incl
480 56 56	4873802	FV 2	Pre-setting tool. FN incl
480 56 57	4873803	FV 3	Pre-setting tool. FN incl
480 56 59	9000047	FL	Pre-setting tool box
480 61 04	4870101	FN 2	Pre-setting key
480 56 58	4870102	FN	Pre-setting key